

316, 318 AND 420 ELECTRICAL SCHEMATIC—SINGLE PTO

A1—TDC Module	M2—Starter Motor:	X5—Rear PTO Harness 3-Pin Connector	X17—Headlight Harness Connector
A2—Ignition Module (S.N. 420001—)	316 (S.N. —362983)	X6—Rear PTO Switch 2-Pin Connector	1-Pin (S.N. —475000)
B1—Engine Oil Pressure Switch	318 (S.N. —364137)	X7—Rear PTO Switch 3-Pin Connector	X18—Tail Light Harness Connector
C1—Condenser (S.N. 420001—)	420 (S.N. —360009)	X8—Brake Switch 2-Pin Connector:	1-Pin (S.N. —475000)
E1—Spark Plug	N1—Voltage Regulator/Rectifier	316 (S.N. 596121—)	2-Pin (S.N. 475001—)
E2—Spark Plug	P1—Front PTO Indicator	318 (S.N. 600305—)	X19—Engine Oil Pressure Switch 1-Pin Connector
E3—Ignition (Breaker) Points (S.N. —420000)	P3—Hour Meter	420 (S.N. 595881—)	X20—Hour Meter 1-Pin Connector
E4—Left Headlight	P4—Battery Discharge Indicator	X9—Transmission Neutral Switch 1-Pin Connector	X21—Hour Meter 1-Pin Connector (Ground)
E5—Middle Headlight	P5—Engine Oil Pressure Indicator	X10—Transmission Neutral Switch 1-Pin Connector	X22—TDC Module 2-Pin Connector
E6—Right Headlight	S1—Key Switch	X11—Seat Switch 2-Pin Connector	X23—TDC Module 8-Pin Connector
E7—Left Tail Light	S2—Front PTO Switch	X12—Engine Harness 3-Pin Connector	X24—Rear PTO Clutch 1-Pin Connector (Ground)
E8—Right Tail Light	S4—Brake Switch:	X13—Voltage Regulator/Rectifier 1-Pin Connector (VDC Output)	X25—Rear PTO Lamp 1-Pin Connector (Ground)
F1—20-Amp Fuse	316 (S.N. 596121—)	X14—Voltage Regulator/Rectifier 1-Pin Connector (Stator)	X26—Front PTO Clutch 2-Pin Connector
F2—2-Amp Fuse:	318 (S.N. 600305—)	X15—Voltage Regulator/Rectifier 1-Pin Connector (Stator)	X27—Single Point Ground 1-Pin Connector:
316 (S.N. —475000)	420 (S.N. 595881—)		316 (S.N. 596121—)
318 (S.N. —475000)	S5—Transmission Neutral Switch		318 (S.N. 600305—)
420 (S.N. —595880)	S6—Seat Switch		420 (S.N. 595881—)
3-Amp Fuse:	S7—Headlight Switch		Y1—Front PTO Clutch
316 (S.N. 475001—)	T1—Ignition Coil		
318 (S.N. 475001—)	W1—Engine Ground (S.N. 475001—)		
420 (S.N. 595881—)	X1—Key Switch 5-Pin Connector		
F3—25-Amp Circuit Breaker	X2—Key Switch 1-Pin Connector		
G1—Battery	X3—Front PTO Switch 2-Pin Connector		
G2—Stator Alternator	X4—Front PTO Switch 3-Pin Connector		
K1—Starter Solenoid:			
316 (S.N. —362983)			
318 (S.N. —364137)			
420 (S.N. —360009)			
M1—Starter Motor:			
316 (S.N. 362984—)			
318 (S.N. 364138—)			
420 (S.N. 360010—)			

Legend For Electrical Schematic

NOTE:

Wire colors are the same for all machines. Wire numbers indicated on schematic are for machines (S.N. 475001—).

1. For 316 (S.N. —596120), 318 (S.N. —600304) and 420 (S.N. —595880) machines, brake switch (S4) is not used. Purple wire “710” connects transmission neutral switch directly to terminal “S2” of key switch.


2. For machines (S.N. —475000), a light green wire is used instead of the red “210” wire used on later machines. The green wire connects to terminal “B” of key switch (S1), not to circuit breaker (F3) as does the red “210” wire.

NOTE:


3. The electrical schematic shows ground circuits for machines (S.N. 475001—). For these machines, all component grounds terminate (spliced) inside the main harness with one wire connecting to a single ground point at the engine.


For machines (S.N. —475000), the (blk) ground wires for the PTO lamps, hour meter, and TDC module (2-pin connector) terminate at the right pedestal panel. Exterior components, such as the PTO clutches and head and tail lights use the tractor frame for ground.

316, 318, AND 420 ELECTRICAL SCHEMATIC — SINGLE PTO



316, 318, AND 420 ELECTRICAL SCHEMATIC — SINGLE PTO







M78972


Circuits	SE3-Charging and Engine Instrumentation Circuits	SE4-Ignition Circuits	SE5-Light Circuit
----------	--	-----------------------	-------------------

316, 318, AND 420 ELECTRICAL SCHEMATIC — DUAL PTO



316, 318, AND 420 ELECTRICAL SCHEMATIC — DUAL PTO





M77920

Circuits	SE3-Charging and Engine Instrumentation Circuits	SE4-Ignition Circuits	SE5-Light Circuit
----------	--	-----------------------	-------------------

316, 318 AND 420 ELECTRICAL SCHEMATIC—DUAL PTO

A1—TDC Module	M2—Starter Motor:	X4—Front PTO Switch 3-Pin Connector	X17—Headlight Harness Connector
A2—Ignition Module (S.N. 420001—)	316 (S.N. —362983)	X5—Rear PTO Harness 3-Pin Connector	1-Pin (S.N. —475000)
B1—Engine Oil Pressure Switch	318 (S.N. —364137)	X6—Rear PTO Switch 2-Pin Connector	X18—Tail Light Harness Connector
C1—Condenser (S.N. 420001—)	420 (S.N. —360009)	X7—Rear PTO Switch 3-Pin Connector	1-Pin (S.N. —475000)
E1—Spark Plug	N1—Voltage Regulator/Rectifier	X8—Brake Switch 2-Pin Connector:	2-Pin (S.N. 475001—)
E2—Spark Plug	P1—Front PTO Indicator	316 (S.N. 596121—)	X19—Engine Oil Pressure Switch 1-Pin Connector
E3—Ignition (Breaker) Points (S.N. —420000)	P2—Rear PTO Indicator (Optional)	318 (S.N. 600305—)	X20—Hour Meter 1-Pin Connector
E4—Left Headlight	P3—Hour Meter	420 (S.N. 595881—)	X21—Hour Meter 1-Pin Connector (Ground)
E5—Middle Headlight	P4—Battery Discharge Indicator	X9—Transmission Neutral Switch 1-Pin Connector	X22—TDC Module 2-Pin Connector
E6—Right Headlight	P5—Engine Oil Pressure Indicator	X10—Transmission Neutral Switch 1-Pin Connector	X23—TDC Module 8-Pin Connector
E7—Left Tail Light	S1—Key Switch	X11—Seat Switch 2-Pin Connector	X24—Rear PTO Clutch 1-Pin Connector (Ground)
E8—Right Tail Light	S2—Front PTO Switch	X12—Engine Harness 3-Pin Connector	X25—Rear PTO Lamp 1-Pin Connector (Ground)
F1—20-Amp Fuse	S3—Rear PTO Switch (Optional)	X13—Voltage Regulator/Rectifier 1-Pin Connector (VDC Output)	X26—Front PTO Clutch 2-Pin Connector
F2—2-Amp Fuse:	S4—Brake Switch:	X14—Voltage Regulator/Rectifier 1-Pin Connector (Stator)	X27—Single Point Ground 1-Pin Connector:
316 (S.N. —475000)	316 (S.N. 596121—)	X15—Voltage Regulator/Rectifier 1-Pin Connector (Stator)	316 (S.N. 596121—)
318 (S.N. —475000)	318 (S.N. 600305—)	X16—Headlight Switch 2-Pin Connector	318 (S.N. 600305—)
420 (S.N. —595880)	420 (S.N. 595881—)		420 (S.N. 595881—)
3-Amp Fuse:	S5—Transmission Neutral Switch		Y1—Front PTO Clutch
316 (S.N. 475001—)	S6—Seat Switch		Y2—Rear PTO Clutch (Optional)
318 (S.N. 475001—)	S7—Headlight Switch		
420 (S.N. 595881—)	T1—Ignition Coil		
F3—25-Amp Circuit Breaker	W1—Engine Ground (S.N. 475001—)		
G1—Battery	X1—Key Switch 5-Pin Connector		
G2—Stator Alternator	X2—Key Switch 1-Pin Connector		
K1—Starter Solenoid:	X3—Front PTO Switch 2-Pin Connector		
316 (S.N. —362983)			
318 (S.N. —364137)			
420 (S.N. —360009)			
M1—Starter Motor:			
316 (S.N. 362984—)			
318 (S.N. 364138—)			
420 (S.N. 360010—)			

Legend For Electrical Schematic

NOTE:

Wire colors are the same for all machines. Wire numbers indicated on schematic are for machines (S.N. 475001—).

1. For 316 (S.N. —596120), 318 (S.N. —600304) and 420 (S.N. —595880) machines, brake switch (S4) is not used. Purple wire “710” connects transmission neutral switch directly to terminal “S2” of key switch.


2. For machines (S.N. —475000), a light green wire is used instead of the red “210” wire used on later machines. The green wire connects to terminal “B” of key switch (S1), not to circuit breaker (F3) as does the red “210” wire.

NOTE:

3. The electrical schematic shows ground circuits for machines (S.N. 475001—). For these machines, all component grounds terminate (spliced) inside the main harness with one wire connecting to a single ground point at the engine.

For machines (S.N. —475000), the (blk) ground wires for the PTO lamps, hour meter, and TDC module (2-pin connector) terminate at the right pedestal panel. Exterior components, such as the PTO clutches and head and tail lights use the tractor frame for ground.

ELECTRICAL COMPONENT LOCATION



- 1—Tail Light (2 used)
- 2—Seat Switch
- 3—Rear Electric PTO Clutch (Optional)
- 4—Key Switch
- 5—TDC Module
- 6—Transmission Neutral Start Switch
- 7—Light Switch
- 8—PTO Switches
- 9—2-Amp and 20-Amp Fuse: (See Note)
316 (S.N. —475000)
318 (S.N. —475000)
420 (S.N. —595880)

- 10—Battery
- 11—Positive (+) Battery Cable
- 12—Negative (—) Battery Cable
- 13—Headlights
- 14—Front Electric PTO Clutch
- 15—Stator Alternator
- 16—Ignition Module (S.N. 420001—)
- 17—Spark Plug (2 used)
- 18—Ignition (Breaker) Points (S.N. —420000)

- 19—Ignition Coil
- 20—Condenser
- 21—Hour Meter
- 22—Circuit Breaker
- 23—Starter Solenoid:
316 (S.N. —362983)
318 (S.N. —364137)
420 (S.N. —360009)
- 24—Regulator/Rectifier
- 25—Engine Oil Pressure Switch
- 26—Brake Switch:
316 (S.N. 596121—)
318 (S.N. 600305—)
420 (S.N. 595881—)

- 27—Starter Motor:
316 (S.N. —362983)
318 (S.N. —364137)
420 (S.N. —360009)
- 28—Starter Motor:
316 (S.N. 362984—)
318 (S.N. 364138—)
420 (S.N. 360010—)

NOTE: For machines 316, 318 (S.N. 475001—) and 420 (S.N. 595881—), 3-amp and 20-amp blade type fuses replace the 2-amp

and 20-amp tubular type fuses shown. The blade type fuses are located in the same area as early version.

M31718 -JUN-19/JAN95

240
15
1

STARTING CIRCUIT OPERATION

The function of the starting circuit is to crank the engine by energizing starter motor (M1). PTO switches (S2 and S3), transmission neutral switch (S5), and brake switch (S4) are used as interlock safety switches within the starter circuit. For the starter motor to energize, the following conditions must be met:

- Front and rear PTO switches in OFF position.
- Hydrostatic Control Lever in N/STOP position.
- Brake pedal depressed.
- Key Switch in "START" position.

NOTE: Depressing the brake pedal required only on later models:

316 (S.N. 596121—)
 318 (S.N. 600305—)
 420 (S.N. 595881—)

For all other machines, depressing the brake pedal is not necessary for starter operation.

PTO switches (S2 and S3) are used in the starting circuit to prevent the engine from cranking while the PTO is engaged. Each PTO switch contains two sets of contacts; one for the PTO circuit (lower contact) and the other (upper contact) as a safety interlock for the starting circuit. When the PTO switch is in the ON position (PTO engaged), the PTO switch interlock contacts are open. When the PTO switch is in the OFF position (PTO disengaged), the PTO interlock contacts are closed, allowing current to flow to transmission neutral switch (S5).

The transmission neutral switch is used in the starting circuit to prevent the engine from cranking when the transmission is in gear. When the hydrostatic control lever is in the forward or reverse position, the transmission neutral switch contacts are open. Moving the hydrostatic control lever to the N/STOP position closes the contacts, allowing current to flow to brake switch (S4).

NOTE: Brake switch equipped on machines: 316 (S.N. 596121—), 318 (S.N. 600305—), and 420 (S.N. 595881—) only. For all other machines, current flows from the transmission switch, directly to terminal "S2" on key switch (S1).

The brake switch will prevent the engine from cranking unless the brake pedal is depressed or park


brake is engaged. Depressing the brake pedal closes the brake switch contacts, allowing current to flow to terminal "S2" on key switch (S1).

The key switch initiates current flow through the starting circuit with the use of two sets of contacts. Both contacts are open when the switch is in the OFF position. When the key switch is turned to the START position, both contacts close. If all the interlock switch contacts in the start circuit are closed, current from the battery positive terminal flows through the 25 amp circuit breaker (F3) to terminal "B" on the key switch. Current flows across the closed contacts, out terminal "A" to the 20 amp fuse (F1). From fuse (F1), current flows through the PTO, transmission, and brake (if equipped) switches and flows back to terminal "S2" of the key switch. The current flows across the key switch contacts, then out terminal "S1" to starter solenoid (K2), energizing the solenoid.

NOTE: For machines 316 (S.N. —362983), 318 (S.N. —364137) and 420 (S.N. —360009), a Bendix drive starter motor is used. These starter motors use a remote mounted starter solenoid relay.

Starter solenoid (K2) contains two coil windings called the pull-in and hold-in windings. Current flowing through these coils produce a strong magnetic field which pulls a plunger inward and closes solenoid main contacts (A). Because the starter is a shift type (solenoid mounted on starter), the plunger also moves the starter drive gear outward to mesh with the flywheel ring gear.

When the solenoid contacts close, high current from the battery flows across the solenoid contacts to starter motor (M1), causing it to turn. Because the pull-in windings are grounded through the starter, current will flow through the pull-in windings only as long as the solenoid main contacts are open. When the solenoid contacts close, both ends of the pull-in windings have the same voltage. This causes the current to stop flowing through the pull-in windings. Because the hold-in windings are grounded directly to the chassis, current continues to flow through the hold-in windings. This keeps the solenoid energized (main contacts closed; starter drive engaged) until the key switch is turned to the RUN or OFF position.



- | | | | |
|---------------------------------|--------------------------------------|-------------------------------------|---|
| A—Starter Solenoid Main Contact | S4—Brake Switch: 316 (S.N. 596121—) | X3—Front PTO Switch 2-Pin Connector | X9—Transmission Neutral Switch 1-Pin Connector |
| F1—20 Amp Fuse | 318 (S.N. 600305—) | X5—Rear PTO Harness 3-Pin Connector | X10—Transmission Neutral Switch 1-Pin Connector |
| F3—25 Amp Circuit Breaker | 420 (S.N. 595881—) | X6—Rear PTO Switch 2-Pin Connector | X23—TDC Module 8-Pin Connector |
| G1—Battery | S5—Transmission Neutral Switch | X8—Brake Switch 2-Pin Connector: | |
| K2—Starter Solenoid | X1—Key Switch 5-Pin Connector | 316 (S.N. 596121—) | |
| M1—Starter Motor | X2—Key Switch 1-Pin Connector | 318 (S.N. 600305—) | |
| S1—Key Switch | | 420 (S.N. 595881—) | |
| S2—Front PTO Switch | | | |
| S3—Rear PTO Switch (Optional) | | | |

Starting Circuit Operation

MX,159024020,2 -19-16MAY95

M77921 -19-04MAR95

IGNITION CIRCUIT OPERATION

The function of the ignition circuit is to produce spark across the gap of spark plugs (E1 and E2). The circuit is a battery ignition type that fires both spark plugs simultaneously, thus eliminating the need for a distributor. The ignition circuit automatically stops the engine anytime the operator rises off the seat for more than one second when tractor is in gear or if PTO is engaged.

OPERATOR ON SEAT—MACHINE IN GEAR AND/OR PTO ENGAGED:

When the key switch (S1) is turned to the RUN or START position, current flows from the positive terminal of battery (G1), through circuit breaker (F3), across key switch contacts at terminals "B" and "A", to fuses (F1 and F2). From fuse (F2), current flows across the contacts of seat switch (S6), through time delay IC (E), to switch transistor (D) located inside the TDC module. As long as current from the IC flows to the transistor, the transistor is "switched on". In this state, the transistor completes the path to ground for TDC ignition relay coil (B). The ground path allows current to flow from fuse (F1), through the relay coil to ground. This energizes the relay coil which closes relay contacts (A).

Current from fuse (F1) then flows across ignition relay contacts (A), out the TDC module to ignition coil (T1). The current flows through the coil primary windings, then through ignition module (A2) to ground.

Current flowing through the primary windings produces a magnetic field around the primary and secondary windings.

NOTE: For machines (S.N. —420000), ignition points (E3) are used. The ignition points are actuated by a pushrod that rides on a camshaft lobe.

The ignition module receives a signal from a trigger ring containing permanent magnets (the ring rotates with the engine crankshaft). This signal causes the ignition module to "break" the circuit, momentarily stopping current flow through the primary windings, and cause the magnetic field to collapse across the secondary windings. The collapsing magnetic field induces high voltage in the secondary windings of the ignition coil. The induced voltage flows from one end of the secondary windings, through the two spark plugs (jumping the plug gaps), then back to the opposite end of the secondary windings. The engine

block completes the circuit between the two spark plugs.

When the operator rises from the seat, the seat switch contacts open, causing current to stop flowing to the time delay IC. If the operator does not return to the seat within approximately one second, the time delay IC stops current flow to transistor (D). The transistor will "switch off", causing current through relay coil (B) to stop flowing and de-energize the coil. With the coil no longer energized, relay contacts (A) will open. Current stops flowing to the ignition coil, thus stopping the engine.


NOTE: Driving the machine over rough terrain can cause the seat switch contacts to momentarily open and close. When this happens, the time delay IC allows the engine to operate without interruption.

If the operator returns to the seat within approximately one second, current flow is re-established to the time delay IC before it has a chance to "time out" and stop current flow to the transistor. Current flow is NOT interrupted to the ignition coil and the engine is allowed to continue operating.

OPERATOR OFF SEAT—MACHINE IN NEUTRAL AND PTO DISENGAGED:

When operator is off the seat, current to the ignition coil can still be maintained through the neutral start (interlock) circuit. For current to flow through the interlock circuit, the key switch must be turned to the RUN or START position, the hydrostatic control lever in the STOP position, the PTO switch(es) in the OFF position (PTO disengaged), and park brake engaged (later models only).

With these conditions met, current flows from terminal "A" of the key switch to fuse (F1). From fuse (F1), current flows through the interlock contacts of the PTO switch(es), transmission neutral switch, and brake switch to terminal "S1" on the key switch. From terminal "S1", current flows to transistor (C) located in the TDC module. As long as current from the interlock circuit flows to transistor (C), the transistor is "switched on". In this state, the transistor provides an alternate path to ground for relay coil (B). The energized relay closes the relay contacts, allowing current to flow to the ignition coil.



- | | |
|------------------------------------|-----------------------------------|
| A—TDC Ignition Relay Contacts | C1—Condenser (S.N. 420001—) |
| B—TDC Ignition Relay Coil | E1—Spark Plug |
| C—Switch Transistor | E2—Spark Plug |
| D—Time Delay Switch Transistor | E3—Ignition Points (S.N. —420000) |
| E—Time Delay IC (Internal Circuit) | F1—20 Amp Fuse |
| A1—Time Delay Control (TDC) Module | F2—2 Amp Fuse (Early Machines) |
| A2—Ignition Module (S.N. 420001—) | F2—3 Amp Fuse (Later Machines) |
| | F3—25 Amp Circuit Breaker |

- | | |
|---------------------------------|--|
| G1—Battery | X12—Engine Harness 3-Pin Connector |
| M1—Starter Motor | X22—TDC Module 2-Pin Connector |
| S1—Key Switch | X23—TDC Module 8-Pin Connector |
| S6—Seat Switch | X27—Single Point Ground 1-Pin Connector: |
| T1—Ignition Coil | 316 (S.N. 596121—) |
| W1—Engine Ground | 318 (S.N. 600305—) |
| X1—Key Switch 5-Pin Connector | 420 (S.N. 595881—) |
| X2—Key Switch 1-Pin Connector | |
| X11—Seat Switch 2-Pin Connector | |

NOTE: 1. For machines 316 (S.N. —596120), 318 (S.N. —600304) and 420 (S.N. —595880), brake switch (S4) is not used. Interlock current flow to transistor (C) comes from transmission neutral start switch (S5).

NOTE: 2. The illustration shows ground circuit for machines (S.N. 475001—). For machines (S.N. —475000), the blk wire from the TDC module 2-pin connector terminates (grounds) at the right pedestal panel.

MX.159024020.4 -19-16MAY95

M77922 -19-04/MAR95

240
15
5

PTO CIRCUIT OPERATION

The function of the PTO circuit is to energize the PTO clutch(es) and turn on the PTO lamp(s). Also, the PTO circuit automatically disengages the PTO clutch(es) anytime the operator rises off the seat for more than one second.

To engage the PTO clutch(es), the following conditions must be met:

- Operator on seat.
- Key Switch at RUN position.
- PTO switches initially at OFF position, then moved to ON position.

When the operator is on the seat and key switch (S1) is turned to the RUN or START position, current flows from the positive terminal of battery (G1), through circuit breaker (F3), to key switch terminal "B". The current flows across the switch contacts to key switch terminal "A". From terminal "A", current flows to fuses (F1 and F2). From fuse (F2), current flows across the closed contacts of seat switch (S6) to pin "9" of TDC module connector (X22).

Inside the TDC module, current flows to time delay IC (A), then to switch transistor (B). As long as current from the IC flows to the transistor, the transistor is "switched on". In this state, the transistor completes the path to ground for PTO relay coil (G).

NOTE: Front PTO switch (S2) and optional rear PTO switch (S3) have two sets of contacts each. One set is used to actuate the clutches and the other set is used in the interlock circuit (see Starting Circuit Theory of Operation in this group).

If machine is not equipped with rear PTO, a jumper wire at 3-pin connector (X5) is used in place of the rear PTO switch.

With the PTO switch(es) in the OFF position, current will flow from fuse (F1) to connector (X3) on the front PTO switch. Current flows across the switch contacts, then to 3-pin connector (X5). If equipped with optional rear PTO, current will flow from connector (X5) to connector (X6) on the rear PTO switch. Current flows across the switch contacts and back out to connector (X5). From connector (X5), current flows to the TDC module, through pin "6" of connector (X23). Inside the TDC module, current flows through diodes (E and F), then through the PTO relay coil and transistor (B) to ground. The interlock circuit current energizes the

PTO relay coil, which closes relay contacts (D). Once the contacts are closed, current flows directly from fuse (F1), across the relay contacts to the relay coil. This current keeps the relay energized (latched) as long as transistor (B) provides a path to ground. Once the coil is latched, current from the interlock circuit is no longer needed to keep the relay energized.

When the front PTO switch is moved to the ON position, current flowing across the relay contacts will also flow to connector (X4) on the front PTO switch, through pin "4" of connector (X23). Current flows across the switch contacts to front PTO clutch (Y1), engaging the clutch. Current also flows to front PTO lamp (P1), turning the lamp on.


NOTE: Operation of optional rear PTO is same as front PTO, except power for rear PTO comes from TDC module through pin "8" of connector (X23).

When the operator rises from the seat, the seat switch contacts open, causing current to stop flowing to the time delay IC. If the operator does not return to the seat within approximately one second, the time delay IC stops current flow to transistor (B). The transistor will "switch off", causing current through the PTO relay coil to stop flowing and de-energize the coil. At this point the PTO relay contacts will open, stopping current flow to the PTO clutch(es) and lamp(s), thus disengaging the PTO clutch(es) and turning the lamp(s) off.

NOTE: Driving the machine over rough terrain can cause the seat switch contacts to momentarily open and close. If this happens, the time delay IC allows the PTO(s) to operate without interruption.

If the operator returns to the seat within approximately one second, current flow is re-established to the time delay IC before it has a chance to "time out" and stop current flow to the transistor. Current flow is NOT interrupted, allowing the PTO(s) to continue operating.

NOTE: Illustration shows component ground for machines (S.N. 475001—). For machines (S.N. —475000), the component ground point is located at right side of pedestal panel.



- | | | | |
|--|-------------------------------|-------------------------------------|--|
| A—Time Delay IC (Internal Circuit) | F3—25 Amp Circuit Breaker | X3—Front PTO Switch 2-Pin Connector | X24—Rear PTO Clutch 1-Pin Connector (Ground) |
| B—Time Delay Switch Transistor | G1—Battery | X4—Front PTO Switch 3-Pin Connector | X25—Rear PTO Lamp 1-Pin Connector (Ground) |
| C—Isolation Diode | M1—Starter Motor | X5—Rear PTO Harness 3-Pin Connector | X26—Front PTO Clutch 2-Pin Connector |
| D—TDC PTO Relay Contacts | P1—Front PTO Lamp | X6—Rear PTO Switch 2-Pin Connector | X27—Single Point Ground 1-Pin Connector: |
| E—Isolation Diode | P2—Rear PTO Lamp (Optional) | X7—Rear PTO Switch 3-Pin Connector | 316 (S.N. 596121—) |
| F—Isolation Diode | S1—Key Switch | X11—Seat Switch 2-Pin Connector | 318 (S.N. 600305—) |
| G—TDC PTO Relay Coil | S2—Front PTO Switch | X22—TDC Module 2-Pin Connector | 420 (S.N. 595881—) |
| A1—Time Delay Control (TDC) Module | S3—Rear PTO Switch (Optional) | X23—TDC Module 8-Pin Connector | Y1—Front PTO Clutch |
| F1—20 Amp Fuse | S6—Seat Switch | | Y2—Rear PTO Clutch (Optional) |
| F2—2 Amp Fuse (Early Machines) 3 Amp Fuse (Later Machines) | W1—Engine Ground | | |
| X1—Key Switch 5-Pin Connector | X1—Key Switch 5-Pin Connector | | |
| X2—Key Switch 1-Pin Connector | X2—Key Switch 1-Pin Connector | | |

MX.159024020,6 -19-16MAY95

-19-04/MAR95
M77923

240
15
7

CHARGING CIRCUIT OPERATION

The function of the charging circuit is to keep the battery properly charged by supplying approximately 13.6—14.7 VDC to the battery while the engine is operating.

The charging system is a permanent magnet and stator type. The magnets are located in the flywheel, which rotates around the stationary stator (G2) windings. Current output is controlled by voltage regulator/rectifier (N1), mounted separately from the stator. Battery discharge lamp (P4) warns the operator when battery discharge lamp control (A) senses low battery voltage. The battery discharge lamp and lamp control DO NOT monitor current output from the stator.

As the flywheel turns, the permanent magnets induce alternating current (AC) in the stator windings. The alternating current flows to the voltage regulator/rectifier. The rectifier portion of the voltage regulator/rectifier converts the alternating current to direct current (DC). The regulator portion stabilizes the direct current and increases or decreases current flow as required by the battery.

Battery discharge lamp control (A) senses battery voltage present at fuse (F2). If the lamp control senses low voltage (less than 12.3 volts), it will provide a path to ground for battery discharge lamp (P4). Since battery voltage is always available at the discharge lamp when the key switch is in the RUN or START position, the ground path provided by the lamp control will allow battery current from fuse (F1) to flow through the battery discharge lamp to ground, lighting the discharge lamp. The lamp will stay on until battery voltage increases to 12.7 volts. At this point, the battery discharge lamp control will break the path to ground, turning the battery discharge lamp off.


Fuses (F1 and F2) protect the battery discharge lamp and lamp control circuit from excessive current.

NOTE: () For machines (S.N. —475000), a light green wire is used instead of the 210 red wire used on later machines. The green wire connects to terminal “B” of key switch (S1), instead of connecting to circuit breaker (F3).*

NOTE: 1. The illustration shows ground circuit for machines (S.N. 475001—).

For machines (S.N. —475000), the blk wire from the TDC module 2-pin connector terminates (grounds) at the right side of the pedestal panel.

MX,159024020,7 -19-16MAY95




- | | | | |
|------------------------------------|--------------------------------|-------------------------------------|--------------------------------|
| A—Battery Discharge Lamp Control | F3—25 Amp Circuit Breaker | S1—Key Switch | X16—Headlight Switch Connector |
| A1—Time Delay Control (TDC) Module | G1—Battery | W1—Engine Ground (See Note) | X22—TDC Module 2-Pin Connector |
| F1—20 Amp Fuse | G2—Stator | X1—Key Switch 5-Pin Connector | X23—TDC Module 8-Pin Connector |
| F2—2 Amp Fuse (Early Machines) | M1—Starter Motor | X2—Key Switch 1-Pin Connector | |
| F3—3 Amp Fuse (Later Machines) | N1—Voltage Regulator/Rectifier | X3—Front PTO Switch 2-Pin Connector | |
| | P4—Battery Discharge Lamp | | |
| | P5—Engine Oil Pressure Lamp | | |

Charging Circuit Operation

MX.159024020,8 -19-16MAY95

OIL PRESSURE LAMP CIRCUIT OPERATION



- | | | | |
|-------------------------------|-------------------------------|-------------------------------------|--------------------------------------|
| B1—Engine Oil Pressure Switch | M1—Starter Motor | X2—Key Switch 1-Pin Connector | X16—Headlight Switch 2-Pin Connector |
| F1—20 Amp Fuse | P5—Engine Oil Pressure Lamp | X3—Front PTO Switch 2-Pin Connector | X23—TDC Module 8-Pin Connector |
| F3—25 Amp Circuit Breaker | S1—Key Switch | | |
| G1—Battery | X1—Key Switch 5-Pin Connector | | |

The purpose of the oil pressure lamp circuit is to warn the operator when engine oil pressure is too low for safe operation of the engine.

Oil pressure switch (B1) is a normally-closed switch. When there is no oil pressure, such as when the engine is not operating, the switch contacts are closed. The closed contacts of the oil pressure switch provide a path to ground for oil pressure lamp (P5).

When the key switch is turned to the RUN or START position, current from the battery flows through circuit breaker (F3), key switch (S1), and 20 amp fuse (F1). From the fuse, current flows through oil pressure lamp (P5), oil pressure switch (B1), then to ground, lighting the oil pressure lamp. The lamp will stay lit until either the key switch is turned to the OFF position or engine oil pressure increases to the point where the pressure switch contacts open, such as during normal engine operation.

Fuse (F1) protects the oil pressure lamp circuit from excessive current.

240
15
10

-19-04/MAR95
M77925