

DIAGNOSING MALFUNCTIONS

Transmission Clutch Slippage

- Restricted filter
- Low system pressure
- Low transmission pump output
- Low transmission oil level

Slippage In First And Third Speeds

- Seal leakage on underdrive brake piston
- Plug leaking or missing from brake housing
- Underdrive brake disks worn excessively

Slippage In Second And Fourth Speeds

- Seals on direct drive clutch piston leaking
- Clutch drum sealing ring leakage
- Plug leaking or missing from brake housing
- Direct drive clutch disks worn excessively

No Change In Speed When Moving Speed

Selector Laterally (Power Shift)

- Linkage broken or disconnected
- Shift valve stuck
- Low system pressure

Low Transmission System Pressure

- Restricted oil filter
- Low transmission oil level
- Low transmission oil pump output
- Transmission oil pump failure
- Weakened or broken pressure regulating valve spring
- Stuck oil filter relief valve
- Torn gaskets behind clutch valve housing or oil filter relief valve housing
- Adapters behind clutch valve housing leaking
- Excessive leakage in Perma-Clutch

Hard To Shift

- Shifter control parts dry
- Shifter quadrants binding
- Neutral-park interlock improperly adjusted
- Shifter cam shaft end play incorrect
- Shifters worn, damaged, or broken
- Cold oil causing Perma-Clutch drag
- Lubrication reduction valve stuck
- Range shifter rod stop improperly adjusted or missing, causing hard shifting out of "park"

Excessive Gear Clash When Shifting

- Excessively worn synchronizer disks
- Operator attempting to shift too fast
- Transmission clutch dragging
- Two-speed rod adjustment incorrect
- Operator not fully disengaging clutch
- Shift lever and cam detent not in proper relation
- Cold oil causing Perma-Clutch drag

Excessive Transmission Noise

- Transmission parts worn or damaged
- Transmission low on oil

TESTING

If transmission malfunction is detected or suspected, check the condition of the oil filter before conducting any tests. Be sure that the filter relief valve is operating properly.

Pressure Test




Fig. 4—Test Plug Locations

To check system pressure, install a 0-300 psi pressure gauge at the clutch test plug on left side of the clutch housing (Fig. 4). Place transmission in "park" position. Disconnect the planetary control valve operating rod from the bell crank (Fig. 39).

Run engine at 1900 rpm. With oil at operating temperature, observe the pressure with the high-low control valve operating arm in both the forward position (direct drive) and rear position (underdrive). Correct oil pressure is 105 to 115 psi.

If pressure for one position is more than 10 psi below pressure for the other, excessive leakage is indicated for the circuit with lower reading. If both positions result in low pressure, install a gauge in the PTO clutch or PTO brake test location. If this pressure is also low, adjust system pressure. If this pressure is normal, the problem is in the clutch valve circuit, oil route connections, or both elements of the planetary are leaking excessively.

To adjust system pressure, remove hex. plug from bottom of pressure regulating valve housing (Fig. 4) and adjust shims below pressure regulating valve spring. One shim equals approximately 5 psi.