

UNIVERSAL SYMBOLS

As a guide to the operation of your tractor, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

| | | | | | | | |
|---|------------------------------|---|------------------------------|---|-----------------------------|---|---|
|  | Thermostart starting aid |  | Radio |  | P.T.O. |  | Position Control |
|  | Alternator charge |  | Keep alive memory |  | Transmission in neutral |  | Draft Control |
|  | Fuel level |  | Turn signals |  | Creeper gears |  | Accessory socket |
|  | Automatic Fuel shut-off |  | Turn signals -one trailer |  | Slow or low setting |  | Implement socket |
|  | Engine speed (rev/min x 100) |  | Turn signals -two trailers |  | Fast or high setting |  | %age slip |
|  | Hours recorded |  | Front wind-screen wash/wipe |  | Ground speed |  | Hitch raise (rear) |
|  | Engine oil pressure |  | Rear wind-screen wash/wipe |  | Differential lock |  | Hitch lower (rear) |
|  | Engine coolant temperature |  | Heater temperature control |  | Rear axle oil temperature |  | Hitch height limit (rear) |
|  | Coolant level |  | Heater fan |  | Transmission oil pressure |  | Hitch height limit (front) |
|  | Tractor lights |  | Air conditioner |  | FWD engaged |  | Hitch disabled |
|  | Headlamp main beam |  | Air filter blocked |  | FWD disengaged |  | Hydraulic and transmission filters |
|  | Headlamp dipped beam |  | Parking brake |  | Warning! |  | Remote valve extend |
|  | Work lamps |  | Brake fluid level |  | Hazard warning lights |  | Remote valve retract |
|  | Stop lamps |  | Trailer brake |  | Variable control |  | Remote valve float |
|  | Horn |  | Roof beacon |  | Pressurized! Open carefully |  | Malfunction! See Operator's Manual |
| | |  | Warning! Corrosive substance | | |  | Malfunction! (alternative symbol) See Operator's Manual |