NO.	Dashboard Fault Code	Fault Code	Warning Lamp		Title
			AMB	RED	
34	s3253 F03	P2455	Solid on		DP sensor high fault
35	s3253 F04	P2454	Solid on		DP sensor low fault
36	s173 F31	P242A	Solid on		DPF In temp sensor fault
37	s173 F03	P242D	Solid on		DPF In temp sensor high fault
38	s173 F04	P242C	Solid on		DPF In temp sensor low fault
39	s173 F02	P242E	Solid on		DPF In temp sensor noise fault
40	s173 F02	P242B	Solid on		DPF In temp sensor plausibility fault
41	s81 F00	P2458	2 Hz		DPF overload fault
42	s81 F07	P2463		2 Hz	DPF plugged fault
43	s81 F11	P242F		1 Hz	DPF regeneration error
44	s1485 F07 s1485 F11	P0685	Solid on or 2 Hz		Main relay fault
45	s27 F10 s27 F31	P0C18		Solid on or 1 Hz	Failure during
46	s27 F08	P0404		1 Hz	EGR position control fault
47	s27 F02	P0402		Solid on	EGR airflow error too high
48	s27 F02	P0401		Solid on	EGR airflow error too low
49	s27 F03	P0406		Solid on	EGR position sensor high fault
50	s27 F04	P0405		Solid on	EGR position sensor low fault
51	s27 F02	P046D		Solid on	EGR position sensor noise fault
52	s27 F03 s27 F04 s27 F05 s27 F11 s27 F16	P0403		Solid on	EGR H-Bridge driver fault
53	s1221 F11	P061B		2 Hz	ECU-Zero Torque Monitoring fault
54	s1221 F11	P1606	Solid on		ECU-Supplementary fault 1
55	s1221 F11	P1607	Solid on		ECU-Supplementary fault 2
56	s1221 F11	P1611	Solid on		ECU-injetor drive disable fail fault
57	s1221 F11	P16D6	Solid on		ECU-engine speed fault
58	s1221 F11	P160C		2 Hz	ECU-engine off fault
59	s1221 F11	P1978	Solid on		ECU-ESC Time out fault
60	s1221 F11	P1612	Solid on		ECU-injector drive disable fault
61	s1221 F11	P16D8	Solid on		ECU-Pedal monitoring fault
62	s1221 F11	P1602	Solid on		ECU-Processor Code Fault
63	s1221 F11	P1601	Solid on		ECU-Processor Data Fault
64	s1221 F11	P1604	Solid on		ECU-Processor RAM Fault
65	s1221 F11	P162B	Solid on		ECU-injector drive lock fail fault