

3/8" hydraulic hoses run to new rear disconnects.

Cut line and add Convert-A-Flare with 3/8" JIC Male x 3/8" JIC male

Cut line and add Convert-A-Flare with 3/8" JIC Male x 3/8" JIC male 90 degree

