

QTY	DESCRIPTION	RUBBER LENGTH	USED IN
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	19"	R.R. CASE DRAIN
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	40"	L.R. CASE DRAIN
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{3}{8}$ " JIC	10"	STEERING HOSE
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{3}{8}$ " JIC	88"	STEERING RETURN
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	21"	LIFT VALVE/MANIFOLD
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	36"	TILT CYLINDER
4	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	15"	LIFT CYLINDER
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	34"	SEAT VALVE RETURN
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	39"	SEAT VALVE PRESSURE
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	48"	DRAFT VALVE PRESSURE
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " TUBE	80"	DRAFT VALVE HOSE
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " NPT	36"	AUX PTO HOSE
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " NPT	29"	AUX PTO HOSE
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	47"	ACCUM./INTERLOCK
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	66"	FOOT VALVE IN/OUT
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	66"	FOOT VALVE PORTS
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x —	39"	FUEL SUCTION
1	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x —	26"	FUEL RETURN
2	$\frac{7}{16}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	66"	SEAT VALVE/cylinder
4	$\frac{7}{16}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " JIC	37"	STEERING HOSE
2	$\frac{1}{4}$ " HOSE - $\frac{1}{4}$ " JIC x $\frac{1}{4}$ " NPT	36"	QUICK ATTACH HOSES