



Fig. 265—Wiring diagram typical of Models 1720 and 1920.

1. Battery
2. Alternator
3. Temperature sender unit
4. Starter motor
5. Glow plug timer
6. Neutral start switch
7. Parking brake switch
8. Key switch
9. Tail light
10. Neutral start switch
11. Hazard warning lights
12. Neutral start switch
13. Light switch
14. Instrument panel lights
15. Fuel sender unit
16. Flasher unit
17. Fuse box
18. Fuel shut-off solenoid
19. Air cleaner sender unit
20. Oil pressure sender unit
21. Glow plugs
22. Headlights