


Starting System Operation—Normal



STARTING SYSTEM OPERATION — NORMAL

LVC4541

LVC4541 -19-06JAN00

Slide LVC4541

Continued on next page

AG.OUO1023,369 -19-09NOV99-1/2