


After new Valve Addition



When Loader is off - Disconnect Qc1
Connect Qc2 to Qc3