



A—Joystick Assembly  
 B—Support  
 C—Right-Hand Shield  
 D—Screw (4 used)

E—Carriage Bolt (50 mm)  
 (1.969 in.)  
 F—Carriage Bolt (5 used)  
 G—Cable

H—Clamp (4 used)  
 I—Pin (2 used)  
 J—Yoke (2 used)  
 K—Plate

L—Left-Hand Shield  
 M—Boot  
 N—Spring Pin

4. Remove shields (C and L).
5. Remove joystick assembly (A).

6. Remove remaining parts. Inspect parts for wear or damage. Replace as necessary.