


Fuses

FUSE #	RATING	COLOR	CIRCUIT
F1/A	10A *	Black	Rear Window Wiper Motor
F1/B	7.5A	Brown	Fuel Shutoff Solenoid
F1/C	10A	Red	Brake Lights, 4-Wheel Braking
F2/A	15A	Blue	Switch Lights, Air Seat, Parking Brake Buzzer
F2/B	15A	Blue	Blower Motor
F2/C	20A	Yellow	Thermostart
F3/A	3A	Violet	A/C Switch Light, Right Side Lights (Opt & Side Shift)
F3/B	3A	Violet	Left Side Lights (Opt & Side Shift)
F3/C	10A	Red	Switches (Front Work Light, Ether Start, Backhoe Quick Attach)
F4/A	5A	Orange	Transmission Shuttle Lever
F4/B	10A	Red	Backhoe Hammer, Loader RTD, Trans Disconnects
F4/C	10A	Red	Switches (Rear Work Light, Backhoe Boom Lock, Side Shift Clamp)
F5/A	15A	Blue	Front Outer Work Lights
F5/B	10A	Red	Opt Headlights : Low Beam
F5/C	15A	Blue	Opt Headlights : High Beam
F6/A	7.5A	Brown	Rotating Beacon
F6/B	7.5A	Brown	Turn Signal Lights
F6/C	7.5A	Brown	4WD Switch, Hand Tool, Tachometer
F7/A	10A	Red	Horn/Hazard Lights
F7/B	10A	Red	Cab Interior Lights, Radio, Aux. Plug
F7/C	10A*	Black	Windshield Wiper Motor
F8/A	15A	Blue	Front Inner Work Lights
F8/B	15A	Blue	Rear Inner Work Lights
F8/C	15A	Blue	Rear Outer Work Lights



*Special bimetal fuse that is auto-resetting

Relays

R1	Transmission Shuttle Lever
R2	Parking Brake Buzzer
R3	Safety Start
R4	Loader Return to Dig
R5	Headlight (Optional & Side Shift)
R6	Front Work Lights Outer
R7	Rear Inner Work Lights
R8	Front Inner Work Lights

R9	Rear Outer Work Lights
Z1	Turn Signal & Hazard Lights Flasher

Buzzer

BZ1	Warning Buzzer
-----	----------------

Connectors

CN	Main Harness Connections into Fuse/Relay Panel
----	--