

ITEM	DESCRIPTION
1.	Stick cylinder
2.	Swing motor
3.	Travel motor (left)
4.	Travel motor (right)
5.	Boom cylinder
6.	Bucket cylinder
7.	Rotary joint
8.	Pressure switch (swing parking brake - option)
9.	Pressure switch (automatic engine control (AEC))
10.	Main control valve
11.	Main relief valve
12.	Pilot control valve (left travel)
13.	Pilot control valve (right travel)
14.	Pilot control valve (swing and stick)
15.	Hydraulic activation control valve
16.	Solenoid valve I (inchingsurface leveling)
17.	Solenoid valve II (crowding/ditch excavation)
18.	Solenoid valve III (swing brake)
19.	Proportional (pressure) reducing valve
20.	Manifold (pilot oil)
21.	Pilot control valve (bucket and boom)
22.	Pilot relief valve
23.	Accumulator
24.	Shock reducing valve
25.	Shuttle valve
26.	Pressure switch (travel alarm - option)
27.	Slow return check valve
28.	Oil cooler
29.	Bypass check valve
30.	Hydraulic tank
31.	Pilot filter
32.	Pump (rear)
33.	Pump (pilot)
34.	Pump (front)

