


Instrument (Dash) Panel



A-PTO Engaged Indicator

B-Air Restriction Indicator

C-High Beam Indicator

D-Hour Meter (LED Digital)

E-Charging System Indicator

F-Park Brake Indicator (See Important)

G-Engine Oil Pressure Indicator

H-Coolant Temperature Gauge

I-Tachometer (See Note)

J-Fuel Gauge

K-Turn Signal Direction Indicators

IMPORTANT: Park brake indicator (F) is not functional.

NOTE: 540E PTO is a factory installed option on SyncShuttle™ transmissions only.