

RETURN PORT FOR JX AND TD5000

If you need a zero pressure port please see the following recommendation

This photo is from early JX the point market is the return port for loader you will need to locally source the necessary fitting to T in this location.

This port is located in the right side of the rear axle



Option number two will be the port on the left side of the rear axle mark with red arrow.



Tractors with the left side port have a return pipe we recommend to keep the pipe in place to prevent aeration

You will need to locally source the necessary fittings to properly T your return line

