


► HST (WITH PTO SWITCH OFF)

(TRAY MOTOR CONTROL)

- : Battery power
- : Ground
- : Power through key switch
- : Controller, switch-signal wiring
- : Controller, power through relay



- SAFETY FIRST
- GENERAL
- ENGINE
- CLUTCH
- TRANSMISSION
- HST
- REAR AXLE
- BEANS
- FRONT AXLE
- STEERING
- HYDRAULIC
- ELECTRIC**