




# Koyker control valve hydraulic line connection guide

For further assistance, call 512-535-6862  
[www.RCOTractor.com](http://www.RCOTractor.com)



High pressure OUT to reservoir

Boom Cylinder

Boom Cylinder, Shaft End

Bucket Cylinder

Bucket Cylinder, Shaft End

High pressure IN from pump