

MAINTENANCE OF THE TRACTOR

SERVICE INTERVALS

No.	Items		Indication on hour meter													Since then	Ref. page		
			50	100	150	200	250	300	350	400	450	500	550	600	650	700			
1	Engine oil	Change	⊙			○				○				○			every 200 Hr	78	
2	Engine oil filter	Replace	⊙			○				○				○			every 200 Hr	77	
3	Transmission oil filter	Replace	⊙			○				○				○			every 200 Hr	78	
4	Transmission fluid	Change								○							every 400 Hr	81	
5	Transmission strainer	Clean	⊙							○							every 400 Hr	82	
6	Front axle case oil	Change								○							every 400 Hr	82	
7	Front axle pivot	Adjust								○							every 400 Hr	81	
8	Engine start system	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 Hr	72	
9	Greasing	—	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 Hr	71	
10	Wheel bolt torque	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	every 50 Hr	73	
11	Battery condition	Check		○		○		○		○		○		○		○	every 100 Hr	73	*5
12	Air cleaner element	Clean		○		○		○		○		○		○		○	every 100 Hr	75	*1
		Replace															every 1 year	83	*2 @
13	Fuel filter	Check		○		○		○		○		○		○		○	every 100 Hr	75	
		Replace										○					every 500 Hr	83	*4 @
14	Fan belt	Adjust		○		○		○		○		○		○		○	every 100 Hr	76	
15	HST neutral spring	Adjust		○		○		○		○		○		○		○	every 100 Hr	76	
16	Brake pedal	Adjust		○		○		○		○		○		○		○	every 100 Hr	77	
17	Radiator hose and clamp	Check				○				○				○			every 200 Hr	79	
		Replace															every 2 years	84	
18	Power steering oil line	Check				○				○				○			every 200 Hr	80	
		Replace															every 2 years	84	*4
19	Fuel line	Check		○		○		○		○		○		○		○	every 100 Hr	75	
		Replace															every 2 years	84	*4 @
20	Intake air line	Check				○				○				○			every 200 Hr	79	
		Replace															every 2 years	84	*4 @
21	Toe-in	Adjust				○				○				○			every 200 Hr	80	
22	Engine valve clearance	Adjust															every 800 Hr	83	*4
23	Fuel injection nozzle Injection pressure	Check															every 1500 Hr	83	*4 @
24	Injection pump	Check															every 3000 Hr	83	*4 @
25	Cooling system	Flush															every 2 years	83	
26	Coolant	Change															every 2 years	83	
27	Fuel system	Bleed															Service as required	84	
28	Fuse	Replace																85	
29	Light bulb	Replace																85	