

This appears to be a long document. Save time by reading a summary using AI Assistant. View Summary



Operator's Front Side Controls



Operator's LH & RH Side Controls

Controls

- | | | |
|---------------------------------|----------------------------|-----------------------------|
| 1. Clutch Pedal | 6. Brake Latch | 11. Differential Lock Pedal |
| 2. Hi-Low Range Selection Lever | 7. RH Brake Pedal | 12. Parking Brake Lever |
| 3. Gear Shifter Lever | 8. Foot Throttle | 13. Seat |
| 4. Hand Throttle Lever | 9. Draft Control Lever | 14. PTO Lever |
| 5. LH Brake Pedal | 10. Position Control Lever | 15. Isolating Valve |
| | | 16. 4WD Engagement Lever |

38

Model - 4550 4WD TIER-4

39 106