


Tooth Caps



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	10500	Cap, Tooth, Standard Pin, T5C/T5D/T6/T7/T9	NA
2	10590	Cap, Tooth, Tiger	NA
3	10591	Cap, Tooth, Tiger, HD	NA
4	10530	Roll Pin, Tooth Cap, SD	NA

Position machine must be in to check proper level in hydraulic tank.



NOTE: Filling tank with loader or backhoe in any other position will result in overfilling and spillage of fluid through the breather cap. Replace cap if oil should ever spill out of breather cap since it will clog off the air supply that the systems needs to operate properly.

- Loader arm lifted off ground a few inches.
- Front loader bucket curled back
- Backhoe boom in full raised position
- Backhoe dipper fully extended
- Backhoe Bucket curled all the way back