

**MF 1040/1045 DUAL CLUTCH**  
**Part 5—Section A**

<b>Operation Number</b>	<b>Table of Contents</b>	<b>Page Number</b>
	OPERATION	42
	TROUBLE-SHOOTING	43
5A—41—44	DUAL CLUTCH Removal and Installation	44
5A—42—46	CLUTCH CONTROL Disassembly and Reassembly	46
5A—43—48	CLUTCH PEDAL Adjustment	48
5A—44—48	PTO CLUTCH CLEARANCE Adjustment	48