

**TOWING THE UTILITY WORK MACHINE**

**Procedure**

In the event that your Toolcat Utility Work Machine needs to be towed, see your Bobcat dealer for instructions.

10-50-1

5600 Service Manual