




Locate this wiring harness  
In next picture

Right mower deck level adjustment

RIO switch the hydrostatic forward pedal triggers when you press the reverse pedal

**WARNING**  
To avoid injury from loaded spring, read operator's manual before changing attachments.



same  
wiring harness  
Previous picture

Need 10mm wrench  
to loosen enough  
so RIO switch is not  
triggered