
2005 JINMA 284
CLUTCH SW
11
12
6
10
BATT
STARTER
FUSE
AMP
30A
REG
10A
HDLT
20A
WKLT
20A
FLSH
7.5A
HORN
10A
HEAT
30A
START SW
ON-2
HT-3
ST-4
INST
PANEL
A-
A+
AMP GAUGE
FUEL GAUGE
TEMP GAUGE
OIL GAUGE
TACH / HOUR
SENSOR
GLOW PLUG
GLOW PLUG
GLOW PLUG
BRAKE SW
BRAKE
LAMP
TAIL
LAMP
INST LT
LAMP
HEAD LT
HEAD
LAMP
WORK LT
WORK
LAMP
L TURN
R TURN
TURN
LAMP
HORN SW
HORN
HORN RLY
FLASHER
VOLT
REG
ALT
RON
MARLETT